



# RTC TOOLS



PART NUMBER	TUBE Ø	TUBE Ø	TUBE Ø
VARI UT006	6X4		
VARI UT008	8X6		
VARI UT010	10X7	10X7,5	10X8
VARI UT012	12X9		
VARI UT015	15X12	16X12	

# 790


- PRESA DI PRESSIONE PNEUMATICA
- TEST POINT
- PRÜFANSCHLÜSSE
- PRISE DE PRESSION PNEUMATIQUE



PART NUMBER	M	Ch	L	L1
790 1215	M12X1,5	18	39	9
790 1615	M16X1,5	22	37	9
790 2215	M22X1,5	28	37	9

# VFF

- PRESA DI PRESSIONE PNEUMATICA
- TEST POINT
- PRÜFANSCHLÜSSE
- PRISE DE PRESSION PNEUMATIQUE



PART NUMBER	F	Ch	L	L1
VFF 1215	M12X1,5	17	39	10
VFF 1615	M16X1,5	22	45	10,8
VFF 1815	M18X1,5	24	47	10,5
VFF 2215	M22X1,5	27	45	11